


Right hand side connections view of each battery






2 x Freedom Lite 15/12 batteries  
3 pole 160 Amp breaker build inside each battery



**IMPORTANT INFORMATION!**  
VEConfigure default settings for Freedom Lite 15/12  
It is important to set default values for the Freedom Lite 15/12 batteries with VEConfigure software in a safe communication with the batteries is interrupted. All default settings for this are available in the Freedom Lite user manual. Confirm the installation of any VEtron assistant and if necessary reset the float voltage to 2.25V.  
Absorption voltage: 55.50V  
Low Pre-Alarm: 51.50V  
Absorption time: 1 hr

**IMPORTANT INFORMATION!**  
Distributed Voltage and Current Control DVCC  
From DVCC software version 2.26, DVCC will be activated ON for Freedom Lite batteries with battery detection ON, as well as enforcing good settings for it: DVCC ON and 50V OFF and 50A OFF. The Controller receives the Charge Voltage Limit, Charge Current Limit, Discharge Current Limit as well as the Battery Low Voltage from the batteries towards the connected Inverters and solar charge. These three disabls their internal charge algorithms and simply do what they're told by the battery.

**IMPORTANT INFORMATION!**  
Checky check with Freedom Won and  
Victron Energy about the latest available  
firmware versions and repair updates.  
Being connecting. It is necessary  
to make sure things meet properly.  
When in doubt, always contact Freedom  
Won and Victron Energy for the latest  
available information.



Drawing BJE283A Rev-B

- IMPORTANT INFORMATION!**  
When operating in inverter mode, the Neutral output of an inverter-charger must be connected to ground to guarantee proper functioning of a GFCI or RCC device. In case of a split phase supply the Neutral should be grounded.  
The primary Case ground connection from an inverter-charger like a Multi or a Quattro, must be connected to the Central Negative Busbar of the DC system. Size of this cable must be identical to connected DC negative.
- IMPORTANT INFORMATION!**  
Quattro 3 phase setup programming  
The 3 phase setup programming has to be completed with VEtron's VE Bus GND Configurator before the ESS assistant is installed into each Quattro.  
Quattro programming with VEConfigure  
The ESS assistant has to be added to each Quattro with VEConfigure after completion of the 3 phase setup.
- IMPORTANT INFORMATION!**  
When Power reset each Quattro size 48V Quattro's  
AC IN-2 output per phase which is present on AC IN-1 or AC IN-2. During Power reset, AC cable length should be input into the cable size of the AC IN-2. An Earth leakage device with breaker or a combination RC/BC/DC must be installed on the output. Cable size must be adjusted accordingly.
- IMPORTANT INFORMATION!**  
Recommended AC Out 1 cable breaker size Quattro's  
AC IN-2 output is available when power is present on AC IN-1 or AC IN-2. During Power reset, AC cable length should be input into the cable size of the AC IN-2. An Earth leakage device with breaker or a combination RC/BC/DC must be installed on the output. Cable size must be adjusted accordingly.
- IMPORTANT INFORMATION!**  
Recommended AC Out 2 cable breaker size Quattro's  
AC IN-2 output is available when power is present on AC IN-1 or AC IN-2. During Power reset, AC cable length should be input into the cable size of the AC IN-2. An Earth leakage device with breaker or a combination RC/BC/DC must be installed on the output. Cable size must be adjusted accordingly.
- IMPORTANT INFORMATION!**  
Recommended DC cable size size 48V Quattro's  
1.5 ft cable length: 2 x 120mm 5-11m cable length: 4 x 750mm. When used in closed conduct, cable size should be adjusted. DC cable length should be the distance between the battery connections and the Quattro connections.  
When used in open conduct, cable size should be adjusted. DC cable length should be the distance between the battery connections and the Quattro connections.  
The system and these also should be taken into account for proper main battery, main fuse & main switch cables. If fuse size should be 200A per Quattro.
- IMPORTANT INFORMATION!**  
Recommended AC IN-1 & AC IN-2 cable breaker size Quattro's  
AC IN-1 & AC IN-2 both must be protected by a circuit breaker rated at least the ampacity of the cable. The separate branch on the side of the connected power source. The input currents must be adjusted to the size of the connected power source.  
AC IN-1 & AC IN-2 both must be protected by a circuit breaker rated at least the ampacity of the cable. The separate branch on the side of the connected power source. The input currents must be adjusted to the size of the connected power source.
- IMPORTANT INFORMATION!**  
230V AC IS EXTREMELY DANGEROUS  
DO NOT TOUCH ANY LIVE WIRE  
PARTS OF THE INSTALLATION!!  
WHEN IN DOUBT, ALWAYS CONSULT  
YOUR VICTRON DEALER!!

FOR A PROPER FUNCTION OF THE 3 PHASE QUATTRO CONFIGURATION, THE PHASE ROTATION FOR GRID/SHORE POWER AND GENERATOR POWER HAS TO BE CONNECTED CORRECTLY FOLLOWING L1,L2,L3

